

INSTALLATION OF PIETRANOVA PRODUCTS

ADVICES:

All substrates on which the PIETRANOVA products are installed must be correctly cured, mechanically strong, free from loose parts, grease, oils, fats, waxes or paint.

Sizes, thicknesses, cleaning, finishes, damaged parts of the products must be checked before the Installation

GRASSI PIETRE declines all liabilities in case of installation of defective pieces.

TILES:

For the installation on cement-based-substrates GRASSI PIETRE recommends a fast-setting and hydrating adhesive (Granirapid Mapei or KEDY S2 Mono). The use of the "buttering floating" technique (double spreading) improves the adhesion between the product and the support. GRASSI PIETRE suggests to wait 2-3 days after tiles' installation for joints grouting , which has to be done using a specific elastic product. For all information concerning the product used for the installation (adhesive, grouting' s mortar etc) please check the producer's technical sheet .

STAIRS:

Stairs must have a minimum thickness of 3 cm. For the installation of stairs on cement-based mortar GRASSI PIETRE recommends a fast-setting and hydrating adhesive (Granirapid Mapei or KEDY S2 Mono). The use of the "buttering floating" technique (double spreading) improves the adhesion between product and support.

GRASSI PIETRE advises an expansion joint of at least 1 cm from eventual points of tension.

For all information concerning the product used for the installation (adhesive, grouting' s mortar etc) please check the producer's technical sheet

RISERS:

Risers have to be installed in the same way of the stairs, GRASSI PIETRE suggests a thickness of 3 cm.

SKIRTINGS:

The installation can be done with the same adhesive used for the tiles. Please use an elastic product for the grouting.

WARNING:

After the installation it is very important to protect the material from filth . GRASSI PIETRE **accept no liabilities** for material damaged after the installation. We recommend to apply to PIETRANOVA a good sealer and wax (if required) after the installation , when the material is dry , to avoid stains. Please find more info on our "Treatment Guidelines" attached.

OUR TECHNICAL DEPARTMENT IS AT YOUR DISPOSAL FOR ANY FURTHER INFORMATION